

# PROGRAMMING RECORD SHEET

FOR MAGNUM ALERT — 800/800UL/800U/800S, CC18/8DD & CC18UL/8U

## CONTROL CENTER FEATURES

FOLD

## COMMUNICATOR FEATURES

ZONE ONE	ZONE TWO	ZONE THREE	ZONE FOUR	ZONE FIVE (PANIC)	ZONE SIX (AUX.)	LOW BATT.	
078	078	078	078	079	079	079	MANUAL SHUNTING
1	2	4	8	1	2		
080	080	080	080	081	081	081	DAY ZONE SUPERVISION
1	2	4	8	1	2		
082	082	082	082	083	083	083	PRIORITY ARMING
1	2	4	8	1	2	4	
084	084	084	084	085	085	085	AUTO-SHUNT ARMING
1	2	4	8	1	2		
086	086	086	086	087	087	087	24 HOUR PROTECTION
1	2	4	8	①	②	④	
088	088	088	088	089	089	089	AUTO-RESET
1	2	4	8	1	2		
090	090	090	090	091	091	091	EXIT/ENTRY DELAY
1	2	4	8	1	2		
094	094	094	094	095	095	095	50 MILLISECOND RESPONSE
1	2	4	8	1	2		
096	096	096	096	097	097	097	750 MILLISECOND RESPONSE
①	2	④	⑧	1	②	④	
106	106	106	106	107	107	107	TIMED ALARM OUTPUT
1	2	4	8	1	2		
108	108	108	108	109	109	109	PULSING ALARM OUTPUT
1	2	4	8	1	2		
110	110	110	110	111	111	111	RELAY CLOSURE ON ALARM
1	2	4	8	1	2		
112	112	112	112	113	113	113	MINI SOUNDER ON ALARM
1	2	4	8	1	2	4	
147	147	147	147	148	148	148	INPUT POLARITY
①	2	④	8	1	2		

### STANDARD FEATURES

	ZONE ONE	ZONE TWO	ZONE THREE	ZONE FOUR	ZONE FIVE (PANIC)	ZONE SIX (AUX.)	LOW BATT.
ABORT DELAY BEFORE DIALING	092	092	092	092	093	093	093
	1	2	4	8	1	2	④
REPORT ON ALARM	098	098	098	098	099	099	099
	1	2	4	8	1	2	4
CONTROL CENTER RESTORAL REPORT	100	100	100	100	101	101	101
	1	2	4	8	1	2	4
ZONE RESTORAL REPORT	114	114	114	114	115	115	115
	1	2	4	8	1	2	4

CLOSING REPORT CODE	014	015
OPENING REPORT CODE	032	033

ADVANCED COMMUNICATOR FEATURES

099	CLOSING REPORT
8	
101	OPENING REPORT
8	
110	TOUCH TONE® DIALING
2	
116	4/2 FORMAT
4	
116	SUM CHECK
8	
117	BACK-UP REPORTING
1	
117	SPLIT REPORTING
2	
118	CONDITIONAL CLOSING REPORT
2	
118	OPENING REPORT AFTER ALARM
8	

CONDITIONAL CLOSING CODE	016	017
OPENING REPORT CODE (AFTER ALARM)	032	033

NOTE: 4/2 OR EXTENDED FORMAT

CUSTOMER:

ADDRESS:


DATE:

### TIME SELECTOR CHART

TIME	1st BOX	2nd BOX
5	5	NONE
15	F	NONE
30	E	1
45	d	2
60	C	3

118 MAINTAINED KEY SWITCH  
1

111 RELAY CLOSURE FOR KEY "ON"  
8



# PROGRAMMING RECORD SHEET COMMUNICATOR TRANSMISSION INFORMATION

FOR MAGNUM ALERT — 800/800UL/800U/800S, CCI8/8DD & CCI8UL/8U

	ZONE ONE	ZONE TWO	ZONE THREE	ZONE FOUR	ZONE FIVE (PANIC)	ZONE SIX (AUX.)	LOW BATT.
<input type="checkbox"/> STANDARD	000	002	004	006	008	010	012
<input type="checkbox"/> 4/2 OR EXTENDED FORMAT REPORTING	001	003	005	007	009	011	013

	ZONE ONE	ZONE TWO	ZONE THREE	ZONE FOUR	ZONE FIVE (PANIC)	ZONE SIX (AUX.)	LOW BATT.
<input type="checkbox"/> STANDARD	U18	U20	U22	U24	U26	U28	U30
<input type="checkbox"/> 4/2 OR EXTENDED FORMAT REPORTING	019	021	023	025	027	029	031

	3rd DIGIT	4th DIGIT	5th DIGIT	6th DIGIT
<input type="checkbox"/> SUBSCRIBER IDENTIFICATION #1	034	035	036	037
<input type="checkbox"/> SUBSCRIBER IDENTIFICATION #2 (for Back-up or Split Reporting only)	038	039	040	041

4th DIGIT  
4/2 FORMAT ONLY  
(see instructions)

	FOR 1st TELEPHONE #	FOR 2nd TELEPHONE #
<input type="checkbox"/> USE ONLY WHERE REQUIRED (see glossary)	042	060

	FOR 1st TELEPHONE #	FOR 2nd TELEPHONE #
<input type="checkbox"/> USE ONLY WHERE REQUIRED (see glossary)	043	061

	FOR 1st TELEPHONE #	FOR 2nd TELEPHONE #
<input type="checkbox"/> SEE GLOSSARY ENTER "E" FOR DIAL TONE DETECTION	044	062

	045	046	047	048	049	050	051	052	053	054	055	056	057
<input type="checkbox"/> 1st TELEPHONE NUMBER													
<input type="checkbox"/> 2nd TELEPHONE NUMBER (for Back-up or Split Reporting only)	063	064	065	066	067	068	069	070	071	072	073	074	075

CENTRAL STATION	RECEIVER
CHOOSE THE APPROPRIATE RECEIVER MASTER FROM:	
<input type="checkbox"/> CCI-7/8-1: Ademco Pulsing Hold	<input type="checkbox"/> CCI-7/8-4: Radionics "fast" format
<input type="checkbox"/> CCI-7/8-2: Ademco, Adcor, Vertex, Silent Knight "slow" format	<input type="checkbox"/> CCI-7/8-5: Silent Knight "fast" format
<input type="checkbox"/> CCI-7/8-3: SESCOA, DCI, Franklin, Vertex "fast" format	<input type="checkbox"/> CCI-7/8-6: Radionics, DCI, Franklin "slow" format