

# Ademco via16 PROGRAMMING FORM

THIS PROGRAMMING FORM INCORPORATES SYSTEM ENHANCEMENTS INVOLVING FIELDS \*28, \*35, \*36, \*49, \*50, \*57, \*76-91 AND MAY ONLY BE USED TO PROGRAM CONTROLS WITH THOSE ENHANCEMENTS.

**FIELD FUNCTION** **PROGRAMMED VALUES** [ ] = Default Value

## SYSTEM ARMING (\*20-\*28)

- \*20 MASTER SECURITY CODE     Enter 4 digits, 0-9 [4][1][1][0]
- \*21 QUICK ARM ENABLE †  [0 = no], 1 = yes
- \*23 FORCED BYPASS FUNCTION †  [0 = no], 1 = yes
- \*24 RF RECEIVER HOUSE ID CODE   With 4281, enter 01-31 House ID. Otherwise enter [00].
- \*28 CONFIRMATION OF ARMING DING †  [0 = no], 1 = yes

## ZONE RESPONSE PROGRAMMING (\*29-\*38)

- \*29 FIRE SOUNDER TIMEOUT DISABLE †  [0 = no], 1 = yes
- \*30 ALARM BELL TIMEOUT †  0 = none; [1 = 4 min]; 2 = 8 min; 3 = 12 min

**ZONE TYPES FOR PROGRAMMING FIELDS \*35-37**

0 = Zone Disabled (or Undefined)  
 1 = ENTRY/EXIT, Burglary  
 2 = not used  
 3 = PERIMETER, Burglary  
 4 = INTERIOR/FOLLOWER, Burglary  
 5 = TROUBLE BY DAY/ALARM BY NIGHT, Burglary  
 6 = 24 Hr (Silent)  
 7 = 24 Hr (Audible)  
 8 = 24 Hr (Auxiliary)  
 9 = FIRE (Fields \*35 and \*37 only)  
 10 = INTERIOR w/DELAY, Burglary (To program, enter # + 10)

- \*35 ZONE 5 RESPONSE TYPE  [9]
- \*36 ZONE 6 RESPONSE TYPE  [3]
- \*37 ZONE 7 RESPONSE TYPE  Console Key B or \* & # Panic. Only zone types 0, [6], 7, 8, 9 applicable.
- \*38 ENTRY DELAY †  0 = 0 sec; 1 = 20 sec; [2 = 30 sec]; 3 = 45 sec  
EXIT Delay = ENTRY Delay + 15 sec

## DIALER PROGRAMMING (\*40-\*49)

- \*40 PABX ACCESS CODE     Enter 4 digits, 0-9. If fewer than 4 digits entered, exit by pressing \* (and press 41, if entering next field). To clear entries from field, press \*40\*.
- \*41 PRIMARY PHONE No.             Enter up to 12 digits, 0-9. Do not fill unused spaces. If fewer than 12 digits entered, exit by pressing \* (and press 42, if entering next field). To clear entries from field, press \*41\*.
- \*42 SECONDARY PHONE No.             Enter up to 12 digits, 0-9. Do not fill unused spaces. If fewer than 12 digits entered, exit by pressing \* (and press 43, if entering next field). To clear entries from field, press \*42\*.
- \*43 SUBSCRIBER ACCOUNT No.     Enter 0-9; #+11 for B; #+12 for C; #+13 for D; #+14 for E; #+15 for F. Enter \* as 4th digit, if 3+1 dialer reporting is to be used. If only 3 digits used, exit by pressing \* (and press 44, if entering next field). To clear entries from field, press \*43\*.

Examples: For Acct No. 1234, enter: 1 2 3 4  
 For Acct No. B234, enter: #+11 2 3 4  
 For Acct No. 123, enter: 1 2 3 \*

- \*44 REPORT FORMAT  [0 = 3+1, 4+1 ADEMCO L/S STANDARD] 6 or undefined = 4+2 ADEMCO EXPRESS  
 1 = 3+1, 4+1 RADIONICS STANDARD 7 = ADEMCO CONTACT ID REPORTING  
 2 = 4+2 ADEMCO L/S STANDARD 8 = 3+1, 4+1 ADEMCO L/S EXPANDED  
 3 = 4+2 RADIONICS STANDARD 9 = 3+1, 4+1 RADIONICS EXPANDED

- \*45 PHONE SYSTEM SELECT †  If Cent. Sta. IS NOT on a WATS line: [0 = Pulse Dial]; 1 = Tone Dial  
 If Cent. Sta. IS on a WATS line: 2 = Pulse Dial; 3 = Tone Dial
- \*46 SESCOA/RADIONICS SELECT †  [0 = Radionics (0-9, B-F reporting)]; 1 = SESCOA (0-9 only reporting)  
 Select 0 for all other formats.
- \*47 15 SEC DIALER DELAY (BURG) †  [0 = no], 1 = yes
- \*48 24 HR TEST MESSAGE †  [0 = no], 1 = yes (enter Test Code in field \*64)

- \*49 SPLIT/DUAL REPORTING  [0 = Backup report only]
 

1 = 2 = 3 = 4 = 5 =	<b>TO PRIMARY PHONE No.</b> Alarms, Restore, Cancel All except Open/Close, Test Alarms, Restore, Cancel All except Open, Close, Test All	<b>TO SECONDARY PHONE No.</b> Others Open/Close, Test All All All
---------------------------------	---	--

† Entry of a number other than one specified will give unpredictable results.

**OVER →**

