


USER'S GUIDE

INTRODUCTION

The 7720P is a serial terminal intended for use with the 7720 or 7920SE Subscriber Radios, and can be used to program, test and diagnose these radios. These instructions will acquaint you with the keyboard functions of the 7720P. Refer to the specific Subscriber Radio's Installation Instructions for detailed programming and test information.



LED INDICATIONS

The 7720P has two LEDs labeled "XMIT" and "SHIFT" which have the following functions:

- XMIT:** Flashes when the host device is transmitting messages.
- SHIFT:** This LED lights when the SHIFT key is pressed and, when lit, indicates that the next keystroke will be the Shift function for a particular key. See SHIFT FUNCTION for more information on the Shift function.

SPECIFICATIONS

- Dimensions:** 7-3/4" x 4-7/16" x 1-1/4"
- Power:** 12VDC supplied by host subscriber radio
- Current drain:** Normal standby = 105 mA

CONNECTING THE 7720P TO THE HOST DEVICE

The 7720P Programming Tool is powered by the host device (7720, 7920SE), and connects to the device's serial/programming telephone connector, using standard telephone cable (supplied).

Connecting to a 7720:

1. Connect the cable from the 7720P to the 7720 programming jack.
2. Power up the 7720, or, if already powered up, press SHIFT-X to reset the system.
3. To enter programming mode, press ENTER [#] while LEDs are flashing consecutively. Refer to the 7720 Installation Instructions for specific programming information.


Connecting to a 7920SE:

Note that a 7720RS Terminal Adapter is required when using the 7720P with a 7920SE.

1. Connect the cable from the 7720P to the 7720P jack on the Terminal Adapter. Connect another cable from the 7920SE jack on the Terminal Adapter to the 7920SE's programming jack. If the 7920SE is already powered up, **hold down the ENTER [#] key while making the connection to the 7920SE.** Holding down the ENTER [#] key sets the baud rate to 9600, which is required when using the 7720P with the 7920SE.
2. Power up the 7920SE (if it wasn't previously powered up), but **hold down the ENTER [#] key while power is being applied.** After a few moments the following prompt should appear: 7920 PROGRAMMER (note that this message may be replaced by incoming data messages).

If 7920SE was previously powered up, press SHIFT-X to reset the system.

3. To enter programming mode, press either C or S or F (depending on the programming mode desired) while the LEDs are flashing. Refer to the 7920SE Installation Instructions for specific programming information.



FUNCTION KEYS

Each key of the 7720P has two possible functions: a normal function and a SHIFT function. The normal function is the function printed on the key itself for numbered keys, or the left hand function for keys having two functions printed above them.

To perform a normal key function, simply press the desired key.

To perform a SHIFT key function, press the SHIFT key first (the SHIFT LED will light), then press desired function key. This is required to select the alphabetical commands/values printed above the numerical keys, or the right hand function for those keys having two functions printed above them. Note that the SHIFT key activates the SHIFT function for the next keystroke only. To select another SHIFT function, the SHIFT key must first be pressed again. The SHIFT key is a toggle function. Therefore, to undo a SHIFT key press (to turn off the SHIFT LED), simply press the SHIFT key a second time.

7720P KEY FUNCTIONS

KEY	FUNCTION
BS/ESC	BACKSPACE [BS]: Used to correct data entries. Each press will delete the data entry to the left of the cursor. ESCAPE [ESC]: Press SHIFT then [ESC] to reset the 7720 EEPROM defaults at the "REVIEW?" prompt. Not used with the 7920SE.
↓/↑	[↓]: Press to scroll to next programming question. [↑]: Press SHIFT then [↑] to scroll to previous programming question.
SCROLL KEY	
N/Y	[N]: Press for "NO" answer.
NO/YES	[Y]: Press SHIFT then [Y] for "YES" answer
SHIFT	Press before selecting a SHIFT key function. Will light SHIFT LED. LED goes out once a key is pressed. Must press again for each SHIFT function desired.
1/A	[1]: Press to enter the number 1 [A]: Press SHIFT then [A]. Used for entering C.S. ID number
2/B	[2]: Press to enter the number 2 [B]: Press SHIFT then [B]. Used for entering C.S. ID number
3/C	[3]: Press to enter the number 3 [C]: Press SHIFT then [C]. Used in 7920SE for entering Central Station Setup Mode. 7920SE & 7720 [C] used for entering C.S. ID number
4/D	[4]: Press to enter the number 4 [D]: Press SHIFT then [D]. Used for entering C.S. ID number
5/E	[5]: Press to enter the number 5 [E]: Press SHIFT then [E]. Used for entering C.S. ID number
6/F	[6]: Press to enter the number 6
FAST	FAST [F]: Press SHIFT then [F]. Used for C.S. ID or for entering FAST mode.
7/S	[7]: Press to enter the number 7 STATUS [S]: Press SHIFT then [S] to display 7720 diagnostic status. 7920SE uses this key to enter Subscriber Setup Mode.
8/T	[8]: Press to enter the number 8
TEST	TEST [T]: Press SHIFT then [T] to send TEST messages.
9/X	[9]: Press to enter the number 9
RESET	RESET [X]: Press SHIFT then [X] to reset the 7720 or 7920SE. Useful when entering program mode after radio is already powered up.
* /SPACE	[*]: Not used. [SPACE]: No SHIFT required. Spaces the cursor forward.
0	[0]: For entering the number 0. No SHIFT function.
#/ENTER	[ENTER]: Press to accept data entries.

ADEMCO LIMITED WARRANTY

Alarm Device Manufacturing Company, a Division of Pittway Corporation, and its divisions, subsidiaries and affiliates ("Seller"), 165 Eileen Way, Syosset, New York 11791, warrants its products to be in conformance with its own plans and specifications and to be free from defects in materials and workmanship under normal use and service for 18 months from the date stamp control on the product or, for products not having an Ademco date stamp, for 12 months from date of original purchase unless the installation instructions or catalog sets forth a shorter period, in which case the shorter period shall apply. Seller's obligation shall be limited to repairing or replacing, at its option, free of charge for materials or labor, any product which is proved not in compliance with Seller's specifications or proves defective in materials or workmanship under normal use and service. Seller shall have no obligation under this Limited Warranty or otherwise if the product is altered or improperly repaired or serviced by anyone other than Ademco factory service. For warranty service, return product transportation prepaid, to Ademco Factory Service, 165 Eileen Way, Syosset, New York 11791.

THERE ARE NO WARRANTIES, EXPRESS OR IMPLIED, OF MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE OR OTHERWISE, WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. IN NO CASE SHALL SELLER BE LIABLE TO ANYONE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, OR UPON ANY OTHER BASIS OF LIABILITY WHATSOEVER, EVEN IF THE LOSS OR DAMAGE IS CAUSED BY THE SELLER'S OWN NEGLIGENCE OR FAULT.

Seller does not represent that the products it sells may not be compromised or circumvented; that the products will prevent any personal injury or property loss by burglary, robbery, fire or otherwise; or that the products will in all cases provide adequate warning or protection. Customer understands that a properly installed and maintained alarm may only reduce the risk of a burglary, robbery, fire or other events occurring without providing an alarm, but it is not insurance or a guarantee that such will not occur or that there will be no personal injury or property loss as a result. **CONSEQUENTLY, SELLER SHALL HAVE NO LIABILITY FOR ANY PERSONAL INJURY, PROPERTY DAMAGE OR OTHER LOSS BASED ON A CLAIM THE PRODUCT FAILED TO GIVE WARNING. HOWEVER, IF SELLER IS HELD LIABLE, WHETHER DIRECTLY OR INDIRECTLY, FOR ANY LOSS OR DAMAGE ARISING UNDER THIS LIMITED WARRANTY OR OTHERWISE, REGARDLESS OF CAUSE OR ORIGIN, SELLER'S MAXIMUM LIABILITY SHALL NOT IN ANY CASE EXCEED THE PURCHASE PRICE OF THE PRODUCT, WHICH SHALL BE THE COMPLETE AND EXCLUSIVE REMEDY AGAINST SELLER.** This warranty replaces any previous warranties and is the only warranty made by Seller on this product. No increase or alteration, written or verbal, of the obligations of this Limited Warranty is authorized.



ALARM DEVICE MANUFACTURING CO.
A DIVISION OF PITTPWAY CORPORATION
165 Eileen Way, Syosset, New York 11791